

Soft Close On/Off, Standard/Full Overlay Cup Hinge



Light

The “Light” setting for the Soft-closing mechanism is set here for light or small doors with very little closing pressure.




Medium

The “Medium” setting for the Soft-closing mechanism is set here for average size doors with normal closing pressure.



Strong

The “Strong” setting for the Soft-closing mechanism is set here for larger or heavier doors with a strong closing pressure. (Factory Setting)



Note:

To reset the Soft-close damper, move the adjustment switch to “Strong”, then to the desired position. Close the door and the Soft-close will be reset.

Soft Close On/Off, Inset Cup Hinge

The SOFT CLOSE can be deactivated on the hinges. SOFT CLOSE comes in the activated position.

Door must be closed once for the deactivation to be complete. To reactivate, move switch back to the original position.

